

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

8022		
- 11	FILE NAM	
1	W:\dists	•
MODEL		

E NAME =	USER NAME = gaglianobt	DESIGNED - R. SHAH	REVISED	-	A. ABBAS 01-20-98
.diststd\22x34\bd22.dgn		DRAWN -	REVISED	-	A. ABBAS 04-27-98
	PLOT SCALE = 50.000 '/ IN.	CHECKED -	REVISED	-	R. BORO 01-01-07
	PLOT DATE = 1/4/2008	DATE - 10-25-94	REVISED	-	R. BORO 09-04-07

STATE OF ILLINOIS
DEPARTMENT OF TRANSPORTATION

PAVEMENT PATCHING FOR					F.A.P. RTE.		
HMA SURFACED PAVEMENT						326	
							BD
NONE	SHEET NO. 1	OF 1	SHEETS	STA.	TO STA.	FFO. R	nan